



ซูเปอร์โคท

ซูเปอร์โคท สีรองพื้นไม้กันเชื้อรา



ซูเปอร์โคท สีรองพื้นไม้กันเชื้อรา ผลิตจาก สารยึดแอลคีด เรซินและผงสีคุณภาพสูง เพื่อการเสริมสภาพผิวไม้ให้อยู่ในสภาพดีก่อนการทาสีทับหน้า เหมาะสำหรับใช้เป็นสีรองพื้นในงานไม้ทั่วไป โดยสามารถใช้เป็นสีชั้นล่างกับพื้นโลหะที่ทารองพื้นที่เหมาะสมกับพื้นผิวมาแล้ว ช่วยเสริมความเนียนเรียบแก่พื้นผิวและการยึดเกาะของสีทับหน้ากับพื้นไม้ อีกทั้งยังมีคุณสมบัติการต่อต้านเชื้อรา และกลบรอยแตกร้าวได้ดี เนื่องจากเนื้อสีแน่น ไม่ผสมสารปรอทและสารตะกั่ว

ข้อมูลทางเทคนิคและคุณสมบัติของฟิล์มสี

ประเภทสี	สีรองพื้นสูตรน้ำมัน
ลักษณะฟิล์มสี	ด้าน
ขนาดบรรจุ	1 และ 5 ยูเอสแกลลอน
เฉดสี	ขาว
เนื้อสีโดยปริมาตร	45- 52%
ระยะเวลาแห้งสัมผัส	2 ชั่วโมง
ระยะเวลาทาทับ	6 - 8 ชั่วโมง
ระยะเวลาแห้งสมบูรณ์	อย่างน้อย 72 ชั่วโมง
การครอบคลุมพื้นที่ตามทฤษฎี	35 - 40 ตร.ม. / เทียว / แกลลอน
*พื้นที่ครอบคลุมเป็นค่าทางทฤษฎี อาจแตกต่างจากการใช้งานจริงไม่เกิน 20%	

วิธีการใช้งาน

วิธีการใช้งาน	แปรง ลูกกลิ้งขนเรียบ หรือสเปรย์
การผสมก่อนใช้งาน	สามารถใช้ได้ทันที หรือเติมน้ำยาผสมสีน้ำมันดูลักซ์ (T850-411) 1 ส่วน ต่อสี 10 ส่วน (ไม่เกิน 10%)
การทำความสะอาด	ล้างทำความสะอาดอุปกรณ์ด้วย น้ำยาผสมสีน้ำมันดูลักซ์ (T850-411) ทันทีหลังการใช้งาน

ระบบการทาสี

การเตรียมพื้นผิว สำหรับพื้นผิวไม้

- พื้นผิวไม้ใหม่
- พื้นผิวไม้เก่า

การทาสีรองพื้นพื้นผิวไม้ทุกประเภท

การทาสีทับหน้า

พื้นผิวต้องสะอาดแห้ง ปราศจากขุยไม้ ควันไฟหรือขีดให้เรียบก่อนทาสี เพื่อให้สีซึมเข้าเนื้อไม้ได้ดี ในการฉาบสีเดิมยังอยู่ในสภาพดี ควรขัดด้วยกระดาษทรายละเอียด ให้พื้นผิวมีความหยาบขึ้นเล็กน้อยเพื่อเสริมการยึดเกาะของสีใหม่ให้ดียิ่งขึ้น แต่หากสีเสื่อมสภาพให้ขัดสีเดิมออกให้หมดจนถึงเนื้อไม้ ให้แน่ใจว่าพื้นผิวสะอาดแห้ง ปราศจากขุยไม้ ก่อนทาสีชั้นถัดไป

(ทาสีรองพื้นให้เหมาะสมกับสภาพพื้นผิวอย่างน้อย 1 เทียว เพื่อป้องกันสิ่งแปลกปลอมจากพื้นผิวสู่สีทับหน้า)

1. ทาสีรองพื้นด้วยสีรองพื้น อลูมิเนียม 1 เทียว เพื่อป้องกันยางไม้และป้องกันการดูดซึมสีเข้าไปในเนื้อไม้มากเกินไป
2. ทาสีรองพื้นไม้กันเชื้อรา ซูเปอร์โคท 1 เทียว เพื่อป้องกันเชื้อรา เสริมการยึดเกาะ เสริมความเรียบเนียนและประหยัดสีทับหน้า ทั้งระยะเวลาให้แห้งสนิทหรือประมาณ 6-8 ชั่วโมง

ทาสีทับหน้าซูเปอร์โคท สีเคลือบเงาหรือสีเคลือบด้าน 2-3 เทียว ด้วยแปรงทาสี ลูกกลิ้งขนเรียบ หรือสเปรย์ โดยทิ้งระยะห่างก่อนทาสีชั้นถัดไปอย่างน้อย 6-8 ชั่วโมง



ISO 9001 QMS03026/630
 ISO 14001 EMS05021/198
 OHSAS 18001 OHSAS04016/079
 TIS 18001 OHS01013/028



Supercote Wood Primer made from a high quality of a quick drying fungus resisting alkylid primer and a high quality pigment. Suitable for general wood work and can be used as undercoat over the correctly primed metal. Specially formulated to support smooth film-built of topcoat. Good filling property with high opacity and use safety as contains no added lead and no added mercury.

Technical Information & Paint Film Properties

Type of Paint	Long Oil Alkyd Enamel Primer
Finish	Matt
Pack size	1 and 5 U.S.Gallons (Ready-mixed)
Colour Offer	White
Volume Solids	45 – 52%
Touch Dry	2 hours
Recoat Dry	8 – 10 hours
Full Cure	At least 72 hours
Theoretical Coverage	35 – 40 Sq.m./coat/gallon

*Coverage is theoretical value and may differ from real application +20%

Application

Application Method	Brush, Short Hair Roller or Spray
Mixing Ratio	Ready to use. Can be thinned with 1 part of clean water to 10 parts of the product (10%)
Cleaning Up	Clean all equipment with clean water immediately after used

Application System

Surface Preparation : Wooden Surface

- *New wood* Surface must be clean, dry and free from all defective or poorly adhering materials, dirt, grease, wax, etc. All surfaces should be rubbed down for good penetration of top coat paint.

- *Old wood* If previous paint is in good condition, rub down with abrasive paper for good adhesion of new paint. If surface is defective or friable, thoroughly rub down until previous paint is totally removed. Ensure that surface is clean, dry and free from all defective or poorly adhering materials, dirt, grease wax, etc. Before painting.

Priming (Apply at least 1 coat of primer to avoid contaminants from surface to top coat paint)

1. Apply 1 coat of Aluminum primer for resisting bitumen or creosote and avoid surface absorb paint too much.
2. Apply 1 coat of Supercote Wood Primer for fungus resistance, enhance adhesion and smoothness of top coat paint. Allow 6 - 8 hours drying.

Coating Apply 2-3 coats of Supercote Enamel Gloss or Matt with brush, short hair roller or spray. Allow 6 – 8 hours drying between coats.



ISO 9001 QMS03026/630
 ISO 14001 EMS05021/198
 OHSAS 18001 OHSAS04016/079
 TIS 18001 OHS01013/028